


The Guest Internet Hotspot Internet gateway products have Ethernet LAN ports that are used to connect wireless access points, Internet café kiosk computers, wired hotel rooms and business center computers. The Internet (WAN) ports must be connected to the DSL or cable modem, or to a T3 or fiber circuit.

First connect the gateway as shown in the diagram to configure it using the setup wizard.

Connect your computer Ethernet connector to the LAN1 connector of the gateway. Your computer Ethernet connector should be configured for dynamic IP or as a DHCP client. It cannot be used with a fixed IP.

Connect the Internet connector of the gateway to the DSL or cable modem LAN Ethernet connector. The DSL or cable modem should have the LAN network connector configured as a DNCP server. Check with the equipment manual to verify the LAN connector configuration.

GIS-R80




Default Port Configuration

For operation the WiFi Hotspot users will use the wireless network or kiosk computers. Connect wireless access points and kiosk computers to the gateway LAN ports.

If you wish to connect more devices then connect an Ethernet switch to one of the LAN ports.

DO NOT DISCONNECT POWER DURING RESET TO AVOID DAMAGE




USE ONLY THE POWER SUPPLY SHIPPED WITH THE UNIT TO PREVENT DAMAGE

Reset to Factory Defaults: Connect the Ethernet cable of the WAN1 port to the computer Ethernet port. Set the computer IP: **192.168.200.2** Open the browser at <http://192.168.200.1> The browser will open a box then enter Username: **reset** Password: **reset** The screen will show a reset button which must be clicked to reset the unit to factory default settings

First Time Product Configuration

Connect your laptop computer to one of the LAN ports of the gateway. Connect the Internet port to your DSL router.

Open your computer browser. Instead of your login page you will see the page shown below. This page is the SETUP WIZARD.



The setup process has four steps. Follow the instructions to type in the information requested on each page. Then click on the button to go to the next page. When the setup process is completed your personalized wireless Internet service will be ready for your guests to start using. The setup process is shown overleaf: flip this page over to start the setup process.

Login to the Admin pages at any time. Connect your computer to the gateway via an Ethernet cable to the LAN port. Then open your browser and type in the URL:

<http://aplogin.com/admin>

The username is **admin**, and the password is the one that you entered with the wizard.

When the page opens select the option you need in the menu. See the manual for more information about configuration.



Hotspot Gateway Product Setup - Quick Start Guide 2

Download the product manual at: <http://www.guest-internet.com/gateway>

Step 1: test the Internet access

Your gateway unit **must have** a connection to the Internet for the configuration process to be completed. If you see a green YES then proceed to step 2. If a red NO then click on the link to diagnose the problem.

You may have to set a 'fixed IP'. If you are not familiar with setting a fixed IP then ask a network technician to provide help with this.

Some DSL and Cable routers have a firewall setting that prevents the gateway from connecting to the Internet. You may have to change a setting on the router firewall.

Test Internet access

Connected to the Internet: YES

If a red NO is showing then you have either not connected this device to the Internet or there is a problem. Make sure you have connected a CAT5 ethernet cable with internet access to the LAN port. If you have a DSL or cable provider then this is the same cable you would use to connect your computer to the modem. If you have just connected the cable to this device then click to test the connection.

If you still see a red NO click to correct the problem.

Continue to step 2

© Fire4 Systems Inc. 2011. Trademarks, service marks and logos are property of their respective owners. Privacy policy Terms and conditions

Step 2: configure hotspot settings

Select your time zone and set your password. Note your password and keep in a safe place.

CONFIGURE PRODUCT: Set the product operating parameters

Time zone: US/Eastern

Admin password: Username: admin
Keep the password safe

Repeat password:

Save setting and continue to step 3

© Fire4 Systems Inc. 2011. Trademarks, service marks and logos are property of their respective owners. Privacy policy Terms and conditions

Step 3: login page branding

Your guests will see this information on the login page

LOGIN PAGE BRANDING: Generate the login page used by customers

Set login page background:

Business center Church Coffee bar Conference
 Hotel Library Marina Motel
 Pool area Sports bar Resort Restaurant
 Custom background image (Uploaded via Login Settings Page)

A custom background image or login page can be added via the advanced login settings page after setup.

Continue to step 2

© Fire4 Systems Inc. 2011. Trademarks, service marks and logos are property of their respective owners. Privacy policy Terms and conditions

Step 4: select guest access

If you select unlimited access then your guests will click on a disclaimer to access the Internet. If you select controlled access then you will have to generate access codes for your guests.

GUEST ACCESS CONTROL: Choose unlimited or controlled Internet access

Unlimited access Controlled access

Login instructions:

Instructions to be displayed to the customers, eg:
 Collect free login token from cashier or
 Please use our free service

Please request a pass code from the harbor master to use this Hot Spot

Save setting and finish wizard

© Fire4 Systems Inc. 2011. Trademarks, service marks and logos are property of their respective owners. Privacy policy Terms and conditions

Finished, click on reboot to start your hotspot

After reboot wait two minutes then open your browser to see your login page. If you want to make changes then login again and click on the setup wizard.

FINISHED: You are ready to go

You will need to reboot this device so the changes take affect. If you changed the Hot Spot name (SSID), you will need to reconnect.

Reboot

© Fire4 Systems Inc. 2011. Trademarks, service marks and logos are property of their respective owners. Privacy policy Terms and conditions